


# Vaikobi størrelseguide

## Padlevester - UNISEX

Size	Float.(N)	Weight (kg)	Chest (cm)
XS	45	40-60	85
S	45	40-60	90
M	60	60<	100
L	60	60<	110
XL	60	60<	120
XXL	60	60<	130+


## Bekledning - Dame

Size	Bust (cm)	Waist (cm)	Hips (cm)
XS	74-84	58-69	82-90
S	85-90	64-70	90-96
M	91-97	71-76	97-102
L	98-103	77-83	103-108
XL	104-109	84-90	109-115
XXL	110-116	91-97	116-122



## Bekledning - Herre og UNISEX

Size	Chest (cm)	Waist (cm)
XS	82-87	66-70
S	89-95	71-76
M	97-102	77-85
L	107-112	86-95
XL	117-122	96-105
XXL	127-132	106-114



### How to measure:

- 1. Chest/Bust:** With arms down at your sides, measure around the largest part of the chest, generally across the nipples.
- 2. Waist:** Measure at the natural waist; above the hip bones, across the navel.
- 3. Hips:** With feet together, measure around the widest part of the hips, across the fullest point of the buttocks.
- 4. Head:** Measure above brow, around the fullest part of the head.

## Fortsatt ikke sikker?

Vår kundeservice hjelper deg gjerne.

Ta kontakt på [info@utinaturen.no](mailto:info@utinaturen.no)

eller telefon 5156 1910